Summitwave RX

Quick Start Guide

Portable Auracast™ Receiver



QSG-RX-EN · Rev. A · 2026-10

Contents

1 Contents of the box 3
2 Five steps to the first sound 4
3 Quick troubleshooting 5
4 Key specifications 6
5 Safe operation 7
6 Compliance and disposal 8
7 Contact 9

1 Contents of the box

Summitwave RX – receiver

Portable receiver with a 1.3″ OLED and a 3.5 mm output for headphones or a hearing loop.

Charger and power supply

Compatible charger for the RX and matching 15 W power supply.

2 Five steps to the first sound

1. **Charge**

   Insert the RX fully into a charging bay of the Summitwave Charger4. A full charge takes 4 hours and lasts for 20 hours of operation.

2. **Connect the audio output**

   Plug headphones or an inductive neck loop fully into the 3.5 mm output. For a hearing loop, activate the telecoil of the hearing system as described in its instructions.

3. **Switch on**

   Press **O**. After start-up, the list of streams currently on air appears.

4. **Select a stream**

   Use **+** / **−** to select the stream name given by the venue, such as “Main Hall English”, and confirm with **O**.

5. **Set the volume**

   Start at a low volume and raise it slowly to a comfortable, clear level.

3 Quick troubleshooting

SYMPTOM	
RX does not start	Battery level and correct seating in the charging station.
Stream not visible	Transmitter active, RX within reception range.
No sound	Audio accessory fully connected, volume and selected stream.
Wrong language or content	Check the selected stream name again.
Sound drops out	Distance, obstacles, state of charge and local radio conditions.
Charging not possible	Charging contacts, seating in the charging bay and power supply of the charging station.

Support
Email: support@summitwave.eu · Phone: +43 670 6020 690

4 Key specifications

FEATURE	
Radio standard	Bluetooth LE Audio (Core 5.3)
Device mode	Auracast™ receiver
Frequency range	2400–2483.5 MHz
Codec	LC3
Audio output	3.5 mm · TRS (stereo)
Output impedance	16–32 Ω
Frequency response	10 Hz–22 kHz
Display	OLED · 1.3″
Battery	Li-Po · typ. 3.6 V · 2000 mAh
Runtime / charging	20 h / 4 h in the charging station
Protection rating	IP44
Dimensions	90 × 60 × 20 mm · approx. 100 g

The full specifications are in the *datasheet*.

5 Safe operation

- Operate only between **−10 °C and +40 °C**. Do not open the housing.
- The RX is rated IP44 but is **not waterproof** – do not immerse it or expose it to water jets.
- **To prevent possible hearing damage, do not listen at high volume levels for long periods.** Start every use at a low volume and raise it only to a comfortable level; with a hearing loop, lower the volume before switching the hearing system over.
- Immediately take the device, cables or battery out of service if they show visible damage, deformation or unusual heating.

6 Compliance and disposal

Manufacturer: Summitwave FlexCo, Hinterwaldner Strasse 16a, AT-6020 Innsbruck, Austria.

SW RX – receive-only device without a transmit function, reception range 2400–2483.5 MHz. Compliance: CE (RED), EN 62368-1, RoHS, REACH, WEEE. Contains a Li-Po battery.

Disposal: Waste electrical and electronic equipment and batteries must not be disposed of with household waste.

7 Contact

Write to support@summitwave.eu or call +43 670 6020 690. Detailed instructions are in the *User Manual*.

Dante® is a registered trademark of Audinate Pty Ltd. Auracast™ is a trademark of Bluetooth SIG, Inc.